



# 3-circuit Square RCS750

## ZRS750 CPS WH (XTS14-3)

White

The Philips 3-circuit square track system consists of an anodised aluminium profile in natural anodised or painted white in lengths of 1, 2, 3 and 4 m. It contains four electrical conductors allowing easy creation of any required configuration: horizontal or vertical, recessed or surface-mounted, on the wall, on free-standing panels or floating. All luminaires have their separate power supply and can be switched selectively by phase or by circuit. Because the luminaires are easy to move, by simply clicking them in place in the adaptor on the track, changes in the lighting and presentation can be made very simply. All 230V projectors in the Philips range can be installed on this track system. All the associated accessories are common to both the surface-mounted and recessed models and guarantee a good electrical and mechanical connection.

### Product data

Operating and Electrical		EAN/UPC - Product	
Input Voltage	250 V	Order code	38122099
General Information		Numerator - Quantity Per Pack	1
Accessory color	White	Numerator - Packs per outer box	5
Product Data		Material Nr. (12NC)	910500187615
Full product code	871155938122099	Full product name	ZRS750 CPS WH (XTS14-3)
Order product name	ZRS750 CPS WH (XTS14-3)	EAN/UPC - Case	8711559381237

## 3-circuit Square RCS750

### Dimensional drawing

