



# 3-circuit Square RCS750

## RCS750 3C L1000 WH (XTS4100-3)

3-circuit Square RCS750, Accessory, White, Tool-protected

The Philips 3-circuit square track system consists of an anodised aluminium profile in natural anodised or painted white in lengths of 1, 2, 3 and 4 m. It contains four electrical conductors allowing easy creation of any required configuration: horizontal or vertical, recessed or surface-mounted, on the wall, on free-standing panels or floating. All luminaires have their separate power supply and can be switched selectively by phase or by circuit. Because the luminaires are easy to move, by simply clicking them in place in the adaptor on the track, changes in the lighting and presentation can be made very simply. All 230V projectors in the Philips range can be installed on this track system. All the associated accessories are common to both the surface-mounted and recessed models and guarantee a good electrical and mechanical connection.

### Product data

General Information	
Accessory color	White
Glow-wire test	Temperature 850 °C, duration 5 s
Mechanical and Housing	
Overall length	1,000 mm
Approval and Application	
Ingress protection code	IP30 [Tool-protected]
Protection class IEC	Safety class I

Product Data	
Full product code	871155938110700
Order product name	RCS750 3C L1000 WH (XTS4100-3)
EAN/UPC - Product	8711559381107
Order code	38110700
Numerator - Quantity Per Pack	1
Numerator - Packs per outer box	1
Material Nr. (12NC)	910500188815
Full product name	RCS750 3C L1000 WH (XTS4100-3)
EAN/UPC - Case	8711559381107
EAN/UPC - Product/Case	8711559381107

## 3-circuit Square RCS750

---

### Dimensional drawing

33 |

