



DALI Square Track

RCS750 5C6 L2000 BK (XTSC6200-2)

DALI Square Track, Normal, Black, Tool-protected

Designed for use with DALI projectors with a dedicated adaptor, the DALI Square Track is ideal for users who want lighting flexibility to create a specific ambience in their shop and to reduce energy consumption. The system is made up of a solid aluminum track, which is available in various lengths and with a choice of electrical conductors. Any given configuration can be easily created – horizontal or vertical, mounted on or in the ceiling, on the wall or on free-standing panels. The system can also be used as a floating structure. All luminaires have a separate power supply and can be switched selectively. They can easily be moved to alter the lighting and presentation. In this way, a multifunctional track system can be created for accent lighting as well as for suspending advertising and decorative material.

Product data

General Information	
Accessory color	Black
Glow-wire test	Temperature 850 °C, duration 5 s
Approval and Application	
Ingress protection code	IP30 [Tool-protected]
Protection class IEC	Safety class I
Product Data	
Full product code	871869606536500
Order product name	RCS750 5C6 L2000 BK (XTSC6200-2)

EAN/UPC - Product	8718696065365
Order code	06536500
Numerator - Quantity Per Pack	1
Numerator - Packs per outer box	1
Material Nr. (12NC)	910502500048
Full product name	RCS750 5C6 L2000 BK (XTSC6200-2)
EAN/UPC - Case	8718696065365
EAN/UPC - Product/Case	8718696065365

DALI Square Track

Dimensional drawing

