



# Maxos, mounting accessories

## 9MX056 CBA WH

Chain bracket adjustable

The light line fulfils two functions: first, it provides a sturdy in-line mounting rail on which to fix the electrical units, and second, it provides a housing for the electrical cables that bring power to the units. For suspended light lines, the light-line sections are connected using the integrated electrical connector and a sturdy external mechanical coupling piece (accessory). Surface-mounted light lines use the same integrated electrical connector and an internal coupler (accessory). On the upper part of the light-line section, special knock-out openings enable cable entry wherever needed. The basic accessories of Maxos TL-D trunkings can also be used for the TL5 trunkings.

### Product data

| General Information               |                                 | Operating and Electrical            |   |
|-----------------------------------|---------------------------------|-------------------------------------|---|
| Protection class IEC              | -                               | Electrical accessories              | No [-]                                  |
| Suspension accessories            | CBA [ Chain bracket adjustable] | Circuit                             | No [-]                                  |
| Mechanical accessories            | No [-]                          | Mechanical and Housing              |   |
| Packaging configuration           | No [-]                          | Length                              | - mm                                    |
| Accessory color                   | White                           | Dimensions (Height x Width x Depth) | NaN x NaN x NaN mm (NaN x NaN x NaN in) |
| Emergency lighting accessories    | No [-]                          | Approval and Application            |   |
| Product family code               | 9MX056 [ ACC MAXOS]             | Ingress protection code             | - [-]                                   |
| Light Technical                   |                                 | Product Data                        |   |
| Optical cover/lens type accessory | No [-]                          | Full product code                   | 403073221754000                         |

## Maxos, mounting accessories

|                                 |               |
|---------------------------------|---------------|
| Order product name              | 9MX056 CBA WH |
| EAN/UPC - Product               | 4030732217540 |
| Order code                      | 21754000      |
| Numerator - Quantity Per Pack   | 1             |
| Numerator - Packs per outer box | 1             |

|                     |              |
|---------------------|--------------|
| Material Nr. (12NC) | 910605108826 |
| Net Weight (Piece)  | 0.115 kg     |

