



3-circuit Square RCS750

ZRS700 SCP ALU SUSP CLAMP (SKB12-1)

3-circuit Square RCS750, Accessory, Aluminum

The Philips 3-circuit square track system consists of an anodised aluminium profile in natural anodised or painted white in lengths of 1, 2, 3 and 4 m. It contains four electrical conductors allowing easy creation of any required configuration: horizontal or vertical, recessed or surface-mounted, on the wall, on free-standing panels or floating. All luminaires have their separate power supply and can be switched selectively by phase or by circuit. Because the luminaires are easy to move, by simply clicking them in place in the adaptor on the track, changes in the lighting and presentation can be made very simply. All 230V projectors in the Philips range can be installed on this track system. All the associated accessories are common to both the surface-mounted and recessed models and guarantee a good electrical and mechanical connection.

Product data

General Information		Numerator - Quantity Per Pack	
Accessory color	Aluminum	Numerator - Quantity Per Pack	1
Product Data		Numerator - Packs per outer box	20
Full product code	871155914985199	Material Nr. (12NC)	910930009618
Order product name	ZRS700 SCP ALU SUSP CLAMP (SKB12-1)	Full product name	ZRS700 SCP ALU SUSP CLAMP (SKB12-1)
EAN/UPC - Product	8711559149851	EAN/UPC - Case	8711559149912
Order code	14985199		

3-circuit Square RCS750

Dimensional drawing

