



# Uni DMX controls and accessories

## ZXP399 DMX amplifier 24V 5P

Uni DMX controls and accessories, 12 to 24 DC V, Dust penetration-protected, jet-proof, CE mark, Black

The ZXP399 DMX Controls and Wiring Accessories are to be used with our architectural and facade lighting luminaires (UniFlood C, M and G, UniStrip G4, UniEdge, UniDot G2, UniString and UniBar). DMX Controls include main controller, stand-alone controller, sub-controllers, DMX amplifier and DMX addressing device. Main Controller: Industrial computer that can control up to 6000 DMX universes. Stand-alone Controller: Fits for medium applications with up to 700 DMX universes. Wiring accessories include leader and jumper cables with male and female IP67 connectors and end-caps. Addressing Device: Hand-held device that can write DMX addresses to a whole run on-site within minutes. DMX Amplifier: Compact, IP65 and low power repeater that can amplify the DMX signal for up to 100 meters.

### Product data

General Information	
Accessory color	Black
CE mark	CE mark
Operating and Electrical	
Input Voltage	12 to 24 DC V
Line Frequency	- Hz
Mechanical and Housing	
Overall length	136.4 mm
Overall width	40 mm

Overall height	25.2 mm
Dimensions (Height x Width x Depth)	25 x 40 x 136 mm
Approval and Application	
Ingress protection code	IP65 [Dust penetration-protected, jet-proof]
Product Data	
Full product code	871951494693499
Order product name	ZXP399 DMX amplifier 24V 5P
Order code	94693499
Numerator - Quantity Per Pack	1

## Uni DMX controls and accessories

Numerator - Packs per outer box	12
Material Nr. (12NC)	911401756692
Full product name	ZXP399 DMX amplifier 24V 5P
EAN/UPC - Case	8719514946934

EAN/UPC - Product/Case	8719514946934
------------------------	---------------

### Dimensional drawing

